

# SC5000 INSTRUCTION MANUAL

Revision Date: 12-30-22

## TABLE OF CONTENTS

Page  
Number

### SECTION 1

#### LEVEL CONTROL

Table Of Contents .....	1-1
Description of Features Available in the Level Control Mode .....	1-2
Control Setup and Data Display .....	1-5
VFD Speed Control .....	1-16
Flush Cycle .....	1-17
Flow Calculator .....	1-18
Connection Diagrams .....	1-24
SC5000-CTS-HMI Screens .....	1-31
SC5000-LED-HMI Menu .....	X-1

### SECTION 2

#### FLOW CONTROL

Table Of Contents .....	2-1
Description of Features Available in the Flow Control Mode .....	2-2
Control Setup and Data Display .....	2-7
Connection Diagrams .....	2-17
SC5000-CTS-HMI Screens .....	2-19

### SECTION 3

#### PRESSURE CONTROL

Table Of Contents .....	3-1
Description of Features Available in the Pressure Control Mode .....	3-2
Control Setup and Data Display .....	3-7
Connection Diagram .....	3-19
SC5000-CTS-HMI Screens .....	3-20

### SECTION 4

#### BOOSTER CONTROL

Table Of Contents .....	4-1
Description of Features Available in the Booster Control Mode .....	4-2
Control Setup and Data Display .....	4-6
Connection Diagrams .....	4-18
SC5000-CTS-HMI Screens .....	4-19

# TABLE OF CONTENTS

Page  
Number

## SECTION A

### DISCRETE INPUTS

Description of Operation .....	A-1
Functions .....	A-2
Setup .....	A-7
Status .....	A-9
Connection Diagrams .....	A-11
SC5000-CTS-HMI Screens .....	A-13

## SECTION B

### RELAY OUTPUTS

Description of Operation .....	B-1
Functions .....	B-1
Setup .....	B-3
Status .....	B-3
Connection Diagram .....	B-4
SC5000-CTS-HMI Screens .....	B-5

## SECTION C

### ANALOG INPUTS

Description of Operation .....	C-1
Functions .....	C-1
Setup .....	C-3
Status .....	C-3
Calibration .....	C-4
Connection Diagram .....	C-6
SC5000-CTS-HMI Screens .....	C-7

## SECTION D

### ANALOG OUTPUTS

Description of Operation .....	D-1
Functions .....	D-1
Setup .....	D-2
Status .....	D-2
Calibration .....	D-3
Connection Diagram .....	D-4
SC5000-CTS-HMI Screens .....	D-5

## SECTION E

### COMMUNICATION PORTS

Description of Operation .....	E-1
Remote Control Command Canceling .....	E-2
Ethernet Port ENET1 & ENET2 Setup .....	E-3
RS232 Port COM1 Setup .....	E-5
SC5000-CTS-HMI Screens .....	E-6

# TABLE OF CONTENTS

Page  
Number

## SECTION F

### FAULT CODES

Description .....	F-1
-------------------	-----

## SECTION G

### PARAMETER SECURITY

Description .....	G-1
SC5000-CTS-HMI Screens .....	G-3

## SECTION H

### BACKUP or RESTORE SETUP PARAMETERS using a USB FLASH DRIVE

Description .....	H-1
SC5000-CTS-HMI Screens .....	H-2

## SECTION I

### RESTORE SETUP PARAMETERS to FACTORY DEFAULTS

Description .....	I-1
SC5000-CTS-HMI Screens .....	I-1

## SECTION J

### PULSE FLOW METERS

Description .....	J-1
Connection Diagrams .....	J-5
SC5000-CTS-HMI Screens .....	J-6

## SECTION K

### ANALOG FLOW METERS

Description .....	K-1
Connection Diagrams .....	K-5
SC5000-CTS-HMI Screens .....	K-6

## SECTION L

### LEVEL PROBE METER

Description .....	L-1
Connection Diagrams .....	L-3
SC5000-CTS-HMI Screens .....	L-4

## SECTION M

### ANALOG LEVEL METERS

Description .....	M-1
Connection Diagrams .....	M-4
SC5000-CTS-HMI Screens .....	M-6

# TABLE OF CONTENTS

Page  
Number

## SECTION N

### ANALOG PRESSURE METERS

Description .....	N-1
Connection Diagrams .....	N-3
SC5000-CTS-HMI Screens .....	N-4

## SECTION O

### ANALOG CURRENT METERS

Description .....	O-1
Connection Diagrams .....	O-4
SC5000-CTS-HMI Screens .....	O-5

## SECTION T

### CONTROL & STATUS BITS

Description .....	T-1
-------------------	-----

## SECTION U

### CONTROLLER DATA

Description .....	U-1
SC5000-CTS-HMI Screens .....	U-2

## SECTION V

### ENCLOSURE MECHANICAL DRAWINGS

Enclosure Front .....	V-1
Enclosure Left Side .....	V-2
Enclosure Right Side .....	V-3
Enclosure Top .....	V-4

## SECTION W

### SC5000-CTS-HMI

Description .....	W-1
Enclosure Front / Panel Cutout .....	W-2
Enclosure Rear and Sides .....	W-3

## SECTION X

### SC5000-LED-HMI

Description .....	X-1
Parameter Menu .....	X-2
Enclosure Front / Panel Cutout .....	X-26
Enclosure Rear and Sides .....	X-27